



1. OPEN THE CASE – Fan out the hinged front and back panels 2. UNLOCK THE UNIT – Turn the screw clockwise 3. RELEASE THE LEVER – Use a letter tile or small tool to press on the lever in the long slot 4. OPEN THE FRAME – Keep the lever pressed as you open the frame 5. ENTER YOUR CHARACTERS – Insert your sensitive information, making sure all filled rows are fully loaded. Use both panels. It helps to set the tiles out in order before you insert them into the frame 6. CLOSE THE CASE – Shut the frame and twist the screw counter-clockwise

product made of stainless steel – fully recyclable / warning: choking hazard – contains small parts

made in Poland